

Remote Programming – GM Trucks 07' and Up

Switch ignition ON.

Repeatedly press vehicle information button (it is usually located on the right or left from the steering column depending on year make and model) until PRESS TO RELEARN remote is displayed.

Press set/reset button until remote key LEARNING ACTIVE is displayed.

Programming mode activated, proceed as follows:

Press and hold lock and unlock buttons on first remote simultaneously for 15 seconds.

Wait for sound signal indicates correct programming.

Repeat above procedure to program remaining remotes.

Switch ignition OFF to exit programming mode.

Remotes can also be programmed using diagnostic equipment.

A maximum of 8 remotes can be programmed.